

Adding a speaker-jack to any amp

Installing a speaker jack is very easy to do and I highly recommend it. First, drill a hole in the chassis (or elsewhere) to accept a 1/4" phone jack. Remove the speaker wires from the speaker, or cut them at the right length to reach the jack. On the speaker cable, pull the two wires apart for about an inch or so. Strip about 3/16" to 1/4" insulation from these wire ends, and solder them to the jack. Now prepare the ends of the wire to the speaker the same way (separate and strip), and solder them to a 1/4" phone plug, making sure the same color wire is ground on the plug as on the jack. Now you can plug your combo speaker in, or plug in an external cab. Easy :-)